


CARBON FILTER INSTALLATION GUIDE

The Litter-Robot 3 is equipped with a Carbon Filter for absorbing odors and controlling moisture in the Waste Drawer. The flexible filter pad can be removed and replaced when cleaning the drawer.

For optimal odor control, we recommend changing the filter every month. If you use scented litter, change the filter more frequently, as it will also absorb the fragrance.

Replacement Carbon Filters can be ordered at www.litter-robot.com.




INSTALLATION

Removal:

1. Pull out the Waste Drawer and locate the Carbon Filter in the front wall.
2. Push the top edge of the filter downward to free it from the hooks.
3. Pull the filter out of the slot and discard.

Installation:

1. In the front wall of the Waste Drawer, slide the new filter into the slot.
2. Bend the top edge of the filter and slide it under each hook.
3. Adjust the filter, so it covers the front-facing vent completely.



Properly installed Carbon Filter

Note: It is normal for the Carbon Filter to shed during installation. Simply wipe up or vacuum any debris.

Visit www.litter-robot.com for installation videos.

SEAL STRIP INSTALLATION GUIDE

The Litter-Robot 3 is equipped with brush-type Seal Strips that sit on the Base under the Globe and help contain odor within the Waste Drawer.

Replace the Seal Strips when they are worn flat or peeling. You can make them last longer by trimming loose edges between replacements.


Seal Strips are not required for the unit to function.

Replacement Seal Strips can be ordered at www.litter-robot.com.



INSTALLATION

1. Press the Power button to turn the unit off, then unplug the unit.
2. Remove the Bonnet and Globe.
For complete instructions, see the Manual.
3. On the Base, peel off the old Seal Strips and discard. Remove any leftover adhesive with a cotton ball and rubbing alcohol. Make sure the surface is dry and free of oils and litter debris before installing new seals.
4. Plan the layout of all four Seal Strips, starting from the corner closest to the Control Panel.
5. Peel back 3-4 inches of the protective backing from the adhesive of one seal and begin placing it along the rib, making sure to curve the strip with the Base. Press down firmly and remove the backing as you go.
6. If the Seal Strip overlaps any grooves or recesses, trim the ends with scissors.
7. Reassemble the Globe and Bonnet, then plug the unit in and turn it on.



Properly installed Seal Strips

Tips

When cleaning the Base, be careful not to wet the Seal Strips or they may begin to peel.

To maintain the Seal Strips, use a lint roller or vacuum to remove debris.

Visit www.litter-robot.com for installation videos.